

INSTRUCTIONS FOR USE AND STORAGE OF BALE NETWRAP



Please read the instructions carefully before using the bale netwrap.

1. Netwrap should be protected from moisture, as this can cause the cardboard tube to soften and get squeezed under the net tension.
2. Rolls must be transported and stored in a horizontal position.
3. Follow the steps below prior to feeding the netwrap into the baler:
 - check the condition of the machine bale chamber and, if necessary, remove dirt or other obstacles that may block the rotating net roll,
 - check the condition of the rubber rollers – the rollers must not have any cavities and cuts on their surface that can damage the net,
 - check the condition of the net cutter: the cutter must be sharp along its whole length, otherwise it may cause entangling of the net in the feeding mechanism and/or incorrect feeding,
 - make sure netwrap brake tension is correctly set:
 - if the brake tension is set too strong pillar breaks or uneven wrapping can occur,
 - if the brake tension is set too loose: uneven net cutting can occur

For best results we suggest to apply the minimum number of netwrap revolutions per crop type:

STRAW: 2-4 revolutions
HAY: 2-3 revolutions
SILAGE: 2-3 revolutions

The product is covered by a two-year warranty.